


Installation Instructions

Stationary Mount

Not suspended

Perpendicular

This mounting method is used when running a stationary curtain perpendicular to a buildings existing I-Beam or Truss structure. This method mounts a Unistrut across the perpendicular ceiling structure in order to provide a continuous mounting surface for the curtain. The perpendicular Unistrut should be supported every 5 feet.



STEP 1 - Make sure you received all the parts you ordered

- Compare the parts that you received with the packing list.
- To visually identify the parts listed on your packing list, please consult the components list found in these installation instructions spanning the last three pages.





Installation Instructions

Stationary Mount Not suspended

Perpendicular to Existing Structure

STEP 2 - A good time to check the height!

Important: The top of the Unistrut that the curtain gets mounted to must be installed at _____ ft. ____ in. off of the floor.


This dimension is also located atop your quotation. There will be a 1" gap between the bottom edge of the curtain and the floor. A floor sweep will cover the open space at the bottom of the curtain if it is included in your purchase.

STEP 3 - Mounting perpendicular Unistrut to the I-Beams/Trusses


Important strut position: Make sure the open side of the strut is facing sideways, not up or down, and faces outward of the enclosed space. This is the side that the curtain will be attached to. The front side of the curtain always faces outward.

The assembled width of the Unistrut (S-1000H3) in the parallel run **must** be equal to the width of the curtain.

Mount the first section of Unistrut across the I-Beams/Trusses at the beginning of the run. Use a U-Bolt beam connector (S2785) on each side of the I-Beam (2 – U-Bolt Connectors per I-Beam). Repeat this process for each Unistrut and I-Beam along the run. If required, cut the last Unistrut to size.



2 x per beam







Installation Instructions Stationary Mount Not suspended


Perpendicular to Existing Structure


STEP 4 - Connect the perpendicular Unistrut to each other.

The Unistrut sections can be connected either as soon as you have two Unistrut's hung up, or in the end once all the Unistrut's are hung. At each Unistrut joint, use either a straight plate connector (S-1067) or a Heavy duty Connector (S-1377 EG). Four bolts and washers are provided for each connection.

Depending on the overall weight of your curtain assembly, you will receive either the connector or the connecting plate.

Unistrut connecting plate








P/N: S1377 EG

STEP 5 - Attach the curtain to the perpendicular Unistrut run

The curtain is attached using **Quick Washers (QW-1062EG)** and a **Bolt (QS-92865).** You have the option to load the Quick Washers into the channel from either the side or the front. Most customers prefer loading the quick washers from the front and twisting them 90° (as indicated by the arrows on the QW) to ensure stability. Once in this position, they can easily be moved sideways within the channel to align with the grommet positions on your curtain.

To begin, line a vertical edge of the curtain with one end of the Unistrut. **Make sure** the **front side** of the curtain faces the outside of the enclosure. Insert a bolt through the grommet on the top edge of the curtain and thread it into the Quick Washer. Repeat this step for **each** grommet along the top of the curtain.



STEP 6 - Important: Secure all hardware connections by tightening all the nuts and bolts. This ensures a safe installation.

Amcraft MANUFACTURING, INC.







Quantity:

Quantity:

Quantity:









Quantity:

Quantity:

Quantity:

Quantity:








Quantity:

Quantity:

Quantity:






Strut connection to Threaded Rod Hardware package P/N: TROD2S Includes: 1 each washer 1 each lock washer 1 each nut 3/8" - 16

Quantity:

Quantity:







Components List: Stationary Mount

Floor Sweep


Velcro attached to the

bottom hem





Quantity:










Quantity:



Quantity:





